

KBL 2.3 SR1 Model Documentation

Class Index

This is the documentation of the VEC UML-Model. The detailed specification of classes and enumerations can be found here:

- [Index - Alphabetical](#)
- [Index - Elements by Module](#)

Documentation Index

The documentation of the specific areas and topics can be found in the following pages.

Note: The diagrams support navigation to the corresponding class descriptions by clicking on the shape of a class.

- [1 Connection Overview](#)
- [2 Common part attributes and properties](#)
- [3 Part specializations](#)
- [4 Harness and Modules](#)
- [5 Part master data](#)
- [6 Connectivity](#)
- [7 Part usage list \(1\)](#)
- [8 Part usage list \(2\)](#)
- [9 Part usage list \(3\)](#)
- [10 Part usage list \(4\)](#)
- [11 Part usage list \(5\)](#)
- [12 Part usage list \(6\)](#)
- [13 Topology and routing \(1\)](#)
- [14 Topology and routing \(2\)](#)
- [15 Dimensions](#)
- [16 Miscellaneous](#)
- [17 KBL_Container](#)

From:

<http://ecad-wiki.prostep.org/> - **prostep ivip WIKI**

Permanent link:

http://ecad-wiki.prostep.org/doku.php?id=models:kbl_v2_3_sr1:start

Last update: **2014/03/18 17:18**

