


[Index](#) - [Previous](#) - [Next](#)

1.3.1 Numerical Values



Since most *NumericalValues* in the VEC are definitions for technical properties, each *NumericalValue* can reference a *Tolerance*. In the example, the specified value of '105.23' has a tolerance of +/- 20.0. Units for *NumericalValues* are defined globally in the VEC and are reused for each *NumericalValue*. The example shows the definition of the *CompositeUnit* Ohm per Kilometre.

[Index](#) - [Previous](#) - [Next](#)

From:
<http://ecad-wiki.prostep.org/> - **prostep ivip WIKI**

Permanent link:
http://ecad-wiki.prostep.org/doku.php?id=tutorials:vec_v1_4:documentation:1_3_1_numerical_values

Last update: **2016/05/12 14:27**

